

FormWeigh.Net®

Reliable and Expandable Formulation Control




Simplify Your Taskswith Smart Formulation

The FormWeigh.Net® system for dispensing and formulation is designed to simplify your complex and demanding formulation needs. Thanks to the intuitive formulation process, you rest assured of stable product quality from batch to batch, while maximizing material utilization, process speed and reducing the amount of manual work involved. Reap the benefits of FormWeigh.Net® in your industry, regardless of whether it is food, pharmaceuticals, chemicals, cosmetics or manufacturing.

The FormWeigh.Net® benefits for your industry:

- Increased productivity
- Guaranteed consistent product quality
- Process safety and stability
- Time savings
- · High flexibility



Achieve Reliable and Traceable Results


Every Time

FormWeigh.Net® works alongside your processes and documents them electronically on the centralized database without compromising your flexibility.

FormWeigh.Net® allows you to take control of your workflows in such a way that you are always aware of which orders are completed, in progress or awaiting processing.

FormWeigh.Net®, the powerful solution with countless advantages:

- Easy to handle
- Centralized data management
- Accelerated material and data flow
- Batch-oriented workflow from incoming goods to shipment
- Batch fraction management and quantity adjustment
- Multiple formulation methods
- Functions compliant with 21 CFR Part 11, 21 CFR Part 111 and EU 178/2002



Increase Production Yield and Maximize Utilization of Raw Materials


In the case of manual processes, stored raw materials may expire before they enter production or they may become unusable as a result of formulation errors.

You may therefore have to dispose of expensive raw materials, drastically reducing your production yield and at the same time incurring additional costs for the disposal of waste.

Thorough operator training and powerful functions, such as FEFO (First Expire – First Out), allow you to fully utilize your materials and reduce waste, which consequently makes your production more cost-effective and environmentally friendly.

FormWeigh.Net® provides:

- Clear procedures and guidance
- Reduced confusion of components
- Verification scanning prior to dispensing




Paper-based dispensing process

Additional costs incurred through process errors

Expired stock

Bad batches

Disposal costs for bad batches and expired materials



FormWeigh.Net® guided process

Boost Your PerformanceIncrease Operator Efficiency

If two people perform the same job, you should benefit from the output of two people. Pharmaceutical companies that do not make use of a supporting system usually apply the countercheck principle in order to comply with regulatory requirements. This means that two people work together to achieve the output of only one person. This is an extremely high price to pay for process reliability, which can be avoided by utilizing a system to provide the second pair of eyes.

FormWeigh.Net® guides your personnel step by step through the dispensing and formulation process. Furthermore, it selects the suitable balance or scale fully automatically. The second person can be assigned to other duties, freeing up resources and increasing productivity.

Key performance indicators of FormWeigh.Net® in pharmaceutical applications:

- · Countercheck no longer required
- Seamless documentation at the push of a button
- Clear material assignment with machine-readable labels
- Automatic API or component adjustment
- Minimized operative overheads (administration and documentation)




In a manual process, two people work together on the same order to countercheck whether it has been executed correctly.



FormWeigh.Net® enables system-guided order processing by one person, doubling the effective productivity

FormWeigh.Net®

Reliable Results Throughout Your Entire Formulation Workflow



METTLER TOLEDO industrial terminals with IP69k compliant ingress protection for hygienically sensitive or harsh environments.



IND780 terminal with embedded FormWeigh.Net® application interface.




The IND560 terminal seamlessly integrates automatic dosing with manual dispensing into the formulation process with FormWeigh.Net®.

ERP Gateway

Optional online exchange of production data with ERP systems (e.g. SAP) to prevent errors and data redundancy.

Production



FormWeigh.Net® allows you to perform your formulation tasks flexibly according to your process requirements.

The system supports and streamlines your dispensing and formulation processes, with clear guidance and full traceability to ensure stable product quality.


Reports

Company			Manufacturing report					FormWeigh.N			
Drier No.			Antiqu to			Anije wein	Pese	ration batch date	Propagation labels and		
21091906-06			R-12501			9901	06.10.2068				
(upplicate)		One product description			Evripodut eraon						
CH-159			Nutribealth Capsules 350			0001					
Butto No.			Set in grantly (septi)			Batch quartly (surrent)					
21091905-06-01			14.000	*		13.947.69					
Sun No.	Material description		Blatter	State	Tare	Target 1875.	TerpetPotency	Current molytic	iter		
Receive No.	Lot No. / Target cont.(5 / Source	ecort. B	tore	See	Of white	Current 1875.	Patency	Total entgre	Properation status		
	Vesper 200		17,00	90, 10, 2003	0.000 kg	8.256 kg	6.00 kg	8.19E+p	SMEW Tateds, Adher		
William .	00-0000W 11		9041	W(3) 50	,	8.106 kg	1083074	A 106 kg	×		
	National action 1.7%		19.30	00 YL2629	2045 0	0.000 kg	6 10 to	860.4	Meller Tatalis Advan		
militar.	00100000 11		84791	90397	*	881.4	1000076	0.500 ng	10		
ten St.	baltudios description			tiere					ter		
Intruction No.				Time					Degrature		
10	Rhong for Encounter		51,00	98.10,3104		OK.			Mother Tribolic Admin		
				14 14 15							
Estable Str.	Material description Lat No. / Target nort (I) / Source		State	Date	Tare Of stone	Current 1875.	Terpethoney	Contract analytic Sense analytic	Properties status		
Manager No.	(anni) in	root t	17.41	0.1.00	1000.0	5.70 to	1104	10.7 4	STREET THESE APPL		
NA.	2000 DR		14,30	W243		1.100 kg	100.00	1707	SERVI SANS. ANN		
M NATIONAL PROPERTY.	Since States settled (0.1000/CC 1.1		19,30	56 VL)658	19143 W	1.004 kg	10000	1,000 to	Matter Talesti, Activi		
Bright III	M-10000 11		Servi.	10.00		401.	1000%	1300 Ng			
**	et ere				P0143 9	1.000 kg	1004				
MICHEL CO.	B1000H 11		\$1091			*****	10830%	1,000 kg	V		
	RESPONSE TO STATE				11114	3.000 kg		3.001 ng 3.001 ng			
26 MCDM	W-0004-0 1-1										


COMPANY	Lot trace list							
Vironal number:	Meterial revision.	Material Ist number:	Material description		QC status		Copry date:	
#42'00	991	DE LIBERTA	athend				BRBII	
Dancole processes (1708)	Recept case: Markages	Polency: 1985	Strage ticator:	Storage zone:	Product of the	(glier)	Supplier number:	
Block Halley (Named &	era)	Scarcity.	Ferrers		DW B	Date	Time	
State unity		40.00 to			NO.	200, 81 (1000)	F1 30 HD	
Stock with draward		48.4	PODE		80	06 H (000	14,3738	
Stud whylased		100.34	Paget		100	36.11,200	11,07,00	
State addition		200 to			80	DE 11 2009	84 18 18	
Total property question		40 M N						
Order number	Febb namber	No.	Ent product No. Balance	(cut) Fodul No.	(sal) Salara		See See	
		19862.3					DE 15,2507 12:00	
practice-or	2001/00/-06-01	1985.5	CHIRI				98 11 JUNE 14:10	
Fotol used for orders		10 10	Tana	used for orders in %			1475	
Stort will-drawn		Sure					-	
Total supply angust.		-0.00 Mg	146	drypatio 3.			140%	
Total stack withdrawn		40.00	Total	of all manufacture bears			1413	
Europi sambous que		erie iş		of sandrosa querily is S			8.55	
Total reas material let qu	and,	GLE 14	has				100.00 %	
Checked	Code			Space		_		
Legend:								
90 mm		and Grimmannine						
Printegrate S-Store			ADMIN T	Stemon 1 S S S			170	

Comprehensive documentation for completed batches ensuring traceability and confirming accurate completion.


Finished Product




Your Daily TasksEasily Accomplished



FormWeigh.Net® order lists displaying pending formulation tasks.



The FormWeigh.Net® weighing station software shows all key component information at a glance, including pictograms, such as hazardous symbols.



IND780 formulation terminal.



Sequence of recipe components and instructions on the component list at the weighing station.



The real-time progress bar is clearly visible to the operator and changes its color according to the weighing progress.



Use Crystal Reports to design your own customized report layouts.





The Flexible and Modular

Standard Formulation Solution



What you stand to gain

- Increased production yield and optimized raw material utilization
- Reduced bad batches and batch re-work
- Less wastage
- · Advanced stock management
- Clear and streamlined processes
- · Seamless recipe handling
- Full traceability throughout your production process
- Increased production flexibility without compromising process stability
- · Increased productivity in dispensing
- Compliance with the FDA and other regulations regarding audit trail and process control, such as 21 CFR Part 11, 21 CFR Part 111 or EU 178/2202
- Fast return on investment

What we promise to provide

- A scalable, standard system, flexibly adapting to your needs
- A modern and continuously updated system for your dispensing and formulation tasks
- Flexible adaption to changing conditions
- Intuitive operation and simple handling
- Terminals and weighing equipment which have been tried and tested in the industry
- Minimum training requirements and maximum prevention of operator errors
- Central data storage with maximum availability
- Ideal interaction between software, hardware and peripherals
- Maximum investment protection through long-term product maintenance and proven upgrade strategies

Find out how FormWeigh.Net $^{\tiny\textcircled{\tiny{\$}}}$ can save you money:


www.mt.com/formulation-calculator

ERP Integration – Seamless Online Data Management

Share data between FormWeigh.Net® and your ERP/MES system

If you maintain your raw materials and orders on your ERP system, the FormWeigh.Net® ERP Gateway brings your efficiency to the next level by exchanging this data through a standardized interface.

FormWeigh.Net® eliminates the need to re-enter master and stock data manually through continuous synchronization with your ERP system. This increases your overall speed and reduces the risk of errors. METTLER TOLEDO offers various types of ERP Gateways, which are compatible with most ERP systems, including SAP.



Professional Software Services

METTLER TOLEDO offers you a wide range of professional services to ensure smooth and efficient project progress and guarantee long-term system reliability.



Implementation consultation

Experienced project engineers plan the implementation of your FormWeigh.Net® system together with you and the future system users.

Your requirements and their realization in the system are clear right from the start, meaning that you won't have any unwanted surprises once the system is in use.



Data integration

If you want your FormWeigh.Net® system to exchange process data with your ERP system, don't hesitate to discuss your requirements with us. We provide consultation and support so that you'll benefit from a seamless integration.

Training

Comprehensive user training will ensure that your operators are familiar with the system and are able to fully utilize it.



Software support

A support agreement ensures that your FormWeigh.Net® system is always running at an optimum performance level. Regular maintenance and updates keep your system up-to-date and guarantee maximum system availability. This protects the investment you made and mitigates against costly upgrades in the future.



Computer system validation

Validation is an absolute must in regulated industries. Right from day one, FormWeigh.Net® was developed to allow efficient and seamless system validation. METTLER TOLEDO offers comprehensive validation documentation (CSV Pac) for supplier audits and IQ/OQ. Experienced and fully trained validation specialists can assist you in this process.



www.mt.com/formulation

For more information

Mettler-Toledo AG

Industrial CH-8606 Greifensee Switzerland Tel. +41 44 944 22 11 Fax +41 44 944 30 60

Subject to technical changes © 04/2010 Mettler-Toledo AG Printed in Switzerland MTSI 21901141